

LOGO READY

ADD YOUR LOGO AT NO EXTRA CHARGE

On-Stage®

	PRODUCT	MODEL NUMBER	ITEM NUMBER	MOQ
	Detachable Sheet Music Stand with Bag	SM7022BB	13047	204
	Compact Sheet Music Stand with Bag	SM7122BB	11052	204
	Compact Sheet Music Stand (Dark Blue) with Bag	SM7122DBB	13039	204
	Compact Sheet Music Stand (Green) with Bag	SM7122GRB	13041	204
	Compact Sheet Music Stand (Nickel) with Bag	SM7122NB	12588	204
	Compact Sheet Music Stand (Purple) with Bag	SM7122PB	13045	204
	Compact Sheet Music Stand (Pink) with Bag	SM7122PKB	13044	204
	Compact Sheet Music Stand (Red) with Bag	SM7122RB	13043	204
	Tripod-Base Sheet Music Stand (Black) with Bag	SM7222BB	13037	204
	Hickory Drum Sticks (2B, Nylon Tip, 12 pairs)	HN2B	11114	120
	Hickory Drum Sticks (5A, Nylon Tip, 12 pairs)	HN5A	11113	120
	Hickory Drum Sticks (5B, Nylon Tip, 12 pairs)	HN5B	11101	120
	Hickory Drum Sticks (7A, Nylon Tip, 12 pairs)	HN7A	11102	120

LOGO READY

ADD YOUR LOGO AT NO EXTRA CHARGE

On-Stage®

	PRODUCT	MODEL NUMBER	ITEM NUMBER	MOQ
	Hickory Drum Sticks (2B, Wood Tip, 12 pairs)	HW2B	11119	120
	Hickory Drum Sticks (5A, Wood Tip, 12 pairs)	HW5A	11118	120
	Hickory Drum Sticks (5B, Wood Tip, 12 pairs)	HW5B	11117	120
	Hickory Drum Sticks (7A, Wood Tip, 12 pairs)	HW7A	11116	120
	Maple Drum Sticks (2B, Nylon Tip, 12 pairs)	MN2B	11124	120
	Maple Drum Sticks (5A, Nylon Tip, 12 pairs)	MN5A	11123	120
	Maple Drum Sticks (5B, Nylon Tip, 12 pairs)	MN5B	11121	120
	Maple Drum Sticks (7A, Nylon Tip, 12 pairs)	MN7A	11120	120
	Maple Drum Sticks (2B, Wood Tip, 12 pairs)	MW2B	11134	120
	Maple Drum Sticks (5A, Wood Tip, 12 pairs)	MW5A	11133	120
	Maple Drum Sticks (5B, Wood Tip, 12 pairs)	MW5B	11129	120
	Maple Drum Sticks (7A, Wood Tip, 12 pairs)	MW7A	11135	120
	Three-Pocket Drum Stick Bag	DSB6700	13471	200

LOGO READY

ADD YOUR LOGO AT NO EXTRA CHARGE




On-Stage®

	PRODUCT	MODEL NUMBER	ITEM NUMBER	MOQ
	Drum Practice Pad with Stand and Bag	DFP5500	11758	204
	Clamp-On Drink Holder	MSA5050	13402	192
	Economy Acoustic Guitar Bag	GBA4550	12476	300
	Economy Bass Guitar Gig Bag	GBB4550	12477	300
	Economy Classical Guitar Bag	GBC4550	12478	300
	Economy Electric Guitar Bag	GBE4550	12548	300
	Standard Acoustic Guitar Gig Bag	GBA4770	13334	300
	Standard Bass Guitar Gig Bag	GBB4770	13339	300
	Standard Classical Guitar Gig Bag	GBC4770	13341	300
	Standard Electric Guitar Gig Bag	GBE4770	13338	300
	Baritone Ukulele Gig Bag	GBU4101	13413	300
	Tenor Ukulele Gig Bag	GBU4102	13414	300
	Soprano Ukulele Gig Bag	GBU4103	13328	300

LOGO READY

ADD YOUR LOGO AT NO EXTRA CHARGE

On-Stage®


	PRODUCT	MODEL NUMBER	ITEM NUMBER	MOQ
	Concert Ukulele Gig Bag	GBU4104	13326	300
	Lighting Stand Bag	LSB6500	35540	120
	Speaker Stand Bag	SSB6500	13160	120
	Foam Shoulder Pad for Violin/Viola (Medium)	VSR1234	13080	120
	Foam Shoulder Pad for Violin/Viola (Small)	VSR1814	13079	120
	Foam Shoulder Pad for Violin/Viola (Large)	VSR3444	13078	120
	24 Pack of Egg Shakers*	HPS1240*	14753	10
	Super Saver Care Kit for Bass Clarinet	BCK5600	13294	36
	Mouthpiece Brush for Brass Instruments	BMB5600	12769	36
	Bow Rosin, Light (Small)	BRA1000	12788	36
	Bow Rosin, Light (Large)	BRL1000	12789	36
	Super Saver Care Kit for Bassoon	BSK5600	13289	36
	Endpin Anchor for Bass/Cello	CBS1000	12790	36

*Additional molding fee applies. | (800) 289-8889 | purchaseorders@musicpeopleinc.com | On-Stage.com

LOGO READY

ADD YOUR LOGO AT NO EXTRA CHARGE

On-Stage®

	PRODUCT	MODEL NUMBER	ITEM NUMBER	MOQ
	Super Saver Kit for Cello	CEK5600	12792	36
	Microfiber Swab for Clarinet	CFS3000	12781	36
	Premium Cork Grease	CGS1500	12765	36
	Super Saver Kit for Clarinet	CLK5600	12791	36
	Synthetic Clarinet Swab	CRS1000	12771	36
	Microfiber Moisture Magnet for Clarinet	CRS5000	12775	36
	Super Saver Care Kit for French Horn	FHK5600	13285	36
	Super Saver Kit for Flute	FLK5600	12793	36
	Synthetic Swabs for Flute (3-Pack)	FRC3000	12772	36
	Microfiber Moisture Magnet for Flute	FRS5000	12776	36
	Information Tag for Band Instruments	IDT1000	12802	36
	Super Saver Kit for Low Brass	LBK5800	12794	36
	Microfiber Cloth	MIC100	12801	36

LOGO READY

ADD YOUR LOGO AT NO EXTRA CHARGE

On-Stage®

	PRODUCT	MODEL NUMBER	ITEM NUMBER	MOQ
	Super Saver Care Kit for Oboe	OBK5600	13292	36
	Synthetic Swab for Alto Sax	SAS2000	12773	36
	Microfiber Swab for Alto Sax	SFS3000	12782	36
	Premium Slide Oil	SOL2000	12768	36
	Deluxe Foam-Padded Strap for Saxophone	SPS5000	12786	36
	Microfiber Moisture Magnet for Alto Saxophone	SRS5000	12777	36
	Super Saver Kit for Alto Saxophone	SXK5800	12795	36
	Super Saver Kit for Trombone	TBK5700	12796	36
	Super Saver Kit for Trumpet	TPK5600	12797	36
	Multipurpose Tuning Slide Grease	TSG1000	12766	36
	Super Saver Kit for Tenor Sax	TSK5700	12798	36
	Super Saver Kit for Viola	VAK5600	12799	36
	Super Saver Kit for Violin	VNK5600	12800	36

LOGO READY

ADD YOUR LOGO AT NO EXTRA CHARGE

On-Stage®

	PRODUCT	MODEL NUMBER	ITEM NUMBER	MOQ
	Premium Valve Oil	VOL2000	12767	36
	Peg Compound for Strings	VPG1000	12787	36
	Bore Brush/Swab for Clarinet/Flute	WCS4000	12774	36
	Mouthpiece Brush for Woodwinds	WMB6600	12770	36